

Možné kombinace neoTower® + Baterie Blackout-Start (BOS)*

neoTower®	BOS 18	BOS 21	BOS 25	BOS 28	BOS 32	BOS 36	BOS 39	BOS 43	BOS 46	BOS 50	BOS 53	BOS 57
2.0	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
3.3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
4.0	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
5.0	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
5.0 Toyota						✓	✓	✓	✓	✓	✓	✓
7.2 Toyota						✓	✓	✓	✓	✓	✓	✓
8.0		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
9.5		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
11.0						✓	✓	✓	✓	✓	✓	✓
11.0 Toyota												✓
12.5						✓	✓	✓	✓	✓	✓	✓
16.0 Toyota												✓
17.0												✓
20.0 Toyota												✓
21.0												✓
25.0												✓
30.0												✓
50.0												

Možné kombinace neoTower® + Baterie Blackout-Start (BOS)*

neoTower®	BOS 64	BOS 71	BOS 75	BOS 78	BOS 85	BOS 89	BOS 92	BOS 96	BOS 100	BOS 107	BOS 114
2.0	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
3.3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
4.0	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
5.0	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
5.0 Toyota	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
7.2 Toyota	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
8.0	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
9.5	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
11.0	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
11.0 Toyota	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
12.5	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
16.0 Toyota	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
17.0	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
20.0 Toyota	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
21.0	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
25.0	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
30.0	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
50.0											✓

(* Pouze při současném objednání)

Pokud jsou mezi BOS a elektrickou sítí připojeny generátory nebo spotřebiče, musí být nabídnuty také následující položky : 3020213 + přímý elektroměr nebo elektroměr s transformátory včetně odpovídající transformátorové sady (nepřímý elektroměr).